

INSTRUCTION MANUAL



Thank you for choosing our Autonics product. Please read the following safety considerations before use.

Safety Considerations

Please observe all safety considerations for safe and proper product operation to avoid hazards. symbol represents caution due to special circumstances in which hazards may occur.

- Warning Failure to follow these instructions may result in serious injury or death. Caution Failure to follow these instructions may result in personal injury or product damage.

Warning

- 1. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.) Failure to follow this instruction may result in personal injury. 2. Do not use the unit in the place where flammable/explosive/corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present. 3. Do not connect, repair, or inspect the unit while connected to a power source. 4. Check the color of cables before wiring. 5. Do not disassemble or modify the unit. 6. This product is not safety sensor and does not observe any domestic nor international safety standard. Do not use this product with the purpose of injury prevention or life protection, as well as in the place where economic loss may be present.

Caution


- 1. Use the unit within the rated specifications. 2. Use dry cloth to clean the unit, and do not use water or organic solvent. 3. Do not use a load over the range of rated relay specification. or contact failure.

Ordering Information

Ordering code structure: BWML 20-24 EC D-... Includes a tree diagram for selecting options like CH ordering orientation, External device connection mode, Operation mode, Control output, Sensing CH, and Sensing target pitch.

This information is intended for product management of custom order option. (no need to refer when selecting model)

Structure



- ① USB port: Do not use this port for the another purpose, or the product can malfunction. ② Comm. status indicator: It displays the communication status through LED. ③ Power cable connector ④ Comm. speed setting switch (B RATE): You can set CC-LINK communication speed. ⑤ Comm. address setting switch: You can set CC-LINK address. (X10: 10, X1: 10) ⑥ CC-LINK comm. connector ⑦ EtherCAT comm. input/output connector: It is with the communication status indicator which turns on or flashes according to the communication status.

Function

Background sensing mode: This function instructs adjusting angle to install the product by displaying presence of the background object in the status display when installing the product. Installation guide mode: This function displays whether the sensing target is in the stable position of the guide line when installing the product through the output indicator. Sensing level setting: This function sets sensitivity by dividing receiving light into 5 levels for stable sensing.



Output option: After setting output option, press key to set additional option. Table with columns: Output option (status display), Description, Additional option, Output option (status display), Description, Additional option.

Self-diagnosis: This function runs self-diagnose periodically in normal operation and displays the part in error at the status display when error occurs. Channel interference alarm, Disturbing light sensing alarm, Emitter/Receiver damage alarm.

Specifications

Table with columns: Model, Sensing type, Sensing distance, Sensing target, Sensing area, Sensing target pitch, Sensing CH, CH ordering orientation, Beam pattern, Power supply, Protection circuit, Current consumption, Operation mode, Response time. Includes sub-tables for CC-LINK and EtherCAT communication parameters.


Dimensions




Installation and Adjustment

- ① Install the product on the right side of the sensing target with the bracket. ② Adjust the height of the product to the place where the first glass of the full cassette is aligned with the installation guide line. ③ Supply the power. ④ Enter to the background sensing mode to detect background. ⑤ Finish installation, when all channels are turned on after placing full cassette. ⑥ If all channels are not turned on, enter to the installation guide mode and adjust the product up and down. Return to the run mode and finish installation, when all channels are turned on.

Mode Switching Method



Operation Timing Diagram



The waveforms of 'Operation indicator' and 'CC-LINK or EtherCAT output' are for Light ON. The waveforms are reversed for Dark ON.

CC-LINK Baud Rate and Address Setting

For CC-LINK setting, communication speed of PLC Master and BWML should be the same. Address is available from 1 to 64 and it should not be duplicated. When changing CC-LINK setting, turn OFF the power of this unit and re-supply the power.

Table with columns: Setting, Baud rate, Address of unit. Includes setting ranges and examples for B RATE and X10, X1.

EtherCAT I/O DATA Structure

Table with columns: 1st Word, Description, 2nd Word, Description. Lists I/O bits for CH1-CH16, ERROR output BIT, and ALARM output BIT.

Since the above is based on the product of 24 CH, the number of I/O is changeable by product. EtherCAT I/O data structure consists of the number of CH+ERROR output BIT+ALARM output BIT.

Operation Indicator

Table with columns: Item, Output indicator (red LED), Stability indicator (green LED). Shows ON/OFF states for Stable, Unstable, and Flashing indicators.

Status indicator

Table with columns: Item, Output indicator, Stability indicator, Status (Green/Yellow/Red), Status display, Communication output. Lists various operational states like Normal operation, Background sensing, and Channel interference error.

If emitter and receiver are damaged at the same time, output of receiver is prior to that of emitter, and lower number of channel indicator is turned on. The indicator of damaged channel is flashed at 0.25 second interval.

Communication status indicator

Table with columns: CC-LINK, Comm. status indicator (green LED). Lists states like STATE, RUN, L/A IN, L/A OUT and their corresponding LED indicators.

Troubleshooting

Table with columns: Malfunction, Cause, Troubleshooting. Lists issues like 'Not operate' and 'Output is ON without a target' with their causes and solutions.

Cautions during Use

- 1. Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents. 2. 24VDC power supply should be insulated and limited voltage/current or Class 2, SELV power supply device. 3. Use the product, 1 sec after supplying power. 4. When using switching mode power supply to supply the power, ground F.G. terminal and connect a condenser between 0V and F.G. terminal to remove noise. 5. When connecting a DC relay or other inductive load, remove surge by using diodes or varistors. 6. Wire as short as possible and keep away from high voltage lines or power lines, to prevent surge and inductive noise. 7. This unit may be used in the following environments.

Major Products

- Photoelectric Sensors, Fiber Optic Sensors, Door Sensors, Area Sensors, Proximity Sensors, Pressure Sensors, Rotary Encoders, Connector/Sockets, Switching Mode Power Supplies, Control Switches/Lamps/Buzzers, I/O Terminal Blocks & Cables, Stepper Motors/Drivers/Motion Controllers, Graphic Logic Panels, Field Network Devices, Laser Marking System (Fiber, Co., Nd: YAG), Laser Welding/Cutting System.

RusAutomation logo and contact information: 454010 г. Челябинск, ул. Гагарина 5, оф. 507. Tel: 8-800-775-09-57.