

Thank you very much for selecting Autonics products. For your safety, please read the following before using.

### Caution for your safety

XPlease keep these instructions and review them before using this unit.

XPlease observe the cautions that follow:

▲ Warning Serious injury may result if instructions are not followed.

△ Caution Product may be damaged, or injury may result if instructions are not followed

XThe following is an explanation of the symbols used in the operation manual. ▲Caution: Injury or danger may occur under special conditions

1. In case of using this unit with machinery(Ex: nuclear power control, medical equpment, ship, vehicle, train, airplane, combustion apparatus, safety device, crime/disaster prevention equipment, etc) which may cause damages to human life or property, it is required to install fail-safe device.

It may cause a fire, human injury or damage to property.

2. This unit is not safety sensor protecting from damages of property or injury from dangerous parts of mechanical equipment, but it is the sensor detecting a normal object or irruption into the working area regardless of safety.

3. Do not use it as safety equipment for the cutter or press.

4. This unit does not follow any international safety standard.
Please check the safety standard of the country the product is used.

5. Please note that we do not take any responsibilities for the problem related to overseas' laws or <p

### ⚠ Caution

- 1. This unit shall not be used outdoors. It might shorten the life cycle of the product or give an electric shock. Use this product inside only. Do not use the product outdoors or location subject to temperatures or humidity outside, (Ex. rain, dirty, frost, sunlight, condensation, etc.)
  2. Do not wire this in power ON status. It may cause an electric shock.
  3. Please use in the rated specifications. It may cause malfunction or life cycle shorter.
  4. Please ground Frame Ground(F.G.) terminal when supplying power by switching power.
  5. Avoid using this unit where there are fluorescent light with high frequency, high speed start or signal light affecting to sensing ability.

- 5. Avoid using this unit where there are fluorescent light with high frequency, high speed start or signa light affecting to sensing ability.
   6. It may be not able to shade the light by reflecting from surface of a wall when installing it in 0.5 from wall or flat parts. Please keep < Installation >.
   7. It may cause malfunction from interference when using them closely in parallel. Please keep < Installation >.
   8. Please install emitter and receiver in same direction. The emitting light is not transferred to receiver

- 8. Please install emitter and receiver in same direction. The emitting light is not transferred to receiver if installed in opposite direction.

  9. Avoid using this unit where there are severe vibration.


  It may cause a fire and malfunction.


  10. In cleaning the unit, do not use water or an oil-based detergent.

  It may cause an electric shock or fire.

  11. Please make power and output line shorten as possible, or it may cause malfunction by surge etc. (Max. 30m)

### Ordering information





ILLD CO	OI LITILLEI			IVeceivei		
Green		POWER		ON		
Yellow		TEST(M/S)		UNSTABLE		
Red				OFF		
<wiring< td=""><td colspan="6"><wiring connection=""></wiring></td></wiring<>	<wiring connection=""></wiring>					
Pin No	Cal	ble color	Emitter		Receiver	
1	Bro	wn	12-24VDC		12 <b>-</b> 24VDC	
2	Wh	ite	SYNC		SYNC	
3	Blu	е	0V		0V	


<Operation indicator >

LED color Emitter

Black TEST(M/S) OUT **%1**: Upper operation indicator is set additionally in case the number of the optical axes is more than 24pcs in BW20-series and more than 12pcs in BW40-series.

### Functions

Light emitted stop function(External diagnosis function)
When TEST input (black) of emitter is 0V, emit is stopped and yellow LED of emitter flashes. It is available to check whether sensor operates properly with stopping the transmission when TEST input (black) of emitter is 0V. (It is changed to light OFF status when emit the transmission is stopped, control output of property is the property of the property



Self-diagnosis function Control output will be OFF and operating indicator is ON when malfunction is checked by self-diagnosis

\*\*Emitter: ①Break of light emitting element ②Break of light emitting circuit

③Maffunction of MASTER/SLAVE line(Operation in MASTER)


\*Receiver: ①Break of light receiving circuit ②Break of output circuit

\*\*Over current and that wat and Supplements line maffunction. ②

③Over current at output part @Synchronous line malfunction

Interference protection function
In case of using 2 pcs of sensor in parallel in order to extend sensing width, it may cause sensing error because as light interference. This function is operating a sensor as MASTER and another sensor as SLAVE to avoid these sensing errors by the light interference.


•Time chart for MASTER/SLAVE light emitting pulse




Specifications


Model		BW20-□(P) BW40-□(P)					
Sensing type		Through-beam					
Sensing of	distance	0.1 to 7m					
Sensing target		Opaque materials of min. ø 30mm	Opaque materials of min. ø 50mm				
Optical axis pitch		20mm	40mm				
Number of optical axes		8 to 48pcs	4 to 24pcs				
Sensing v	width	140 to 940mm	120 to 920mm				
Pointing angle		Within ±5° (At over 3m sensing distance)					
Power supply		12-24VDC ±10%(Ripple P-P: Max. 10%)					
Reverse power protection circuit		Built in					
Current consumption		Emitter: Max. 80mA, Receiver: Max. 80mA					
Control output		NPN or PNP open collector output  Load voltage: Max. 30VDC Load current: Max. 100mA Residual voltage - NPN: Max. 1V, PNP: Max. 2.5V					
Operation mode		Light ON only					
Short-circuit protection		Built-in					
Response time		Min. 12ms					
Light sou	rce	Infrared LED(850nm modulated)					
Synchronization type		Synchronous method by synchronous line					
Self-diagnosis		Ambient light monitoring, Emitter/Receiver light circuit monitoring, Output circuit monitoring					
Interferen	ice protection	Interference protection by master/slave function					
	Ambient illumination	Sunlight: Max. 10,000/x					
Environ- ment	Ambient temperature	-10 to +55°C, Storage: -20 to +60°C					
Ambient humidity		35 to 85%RH, Storage: 35 to 85%RH					
Noise stre	ength	The square wave noise by the noise solution (Voltage: ±240V, Period: 10ms, Puls					
Dielectric	strength	1,000VAC 50/60Hz for 1minute					
Insulation	resistance	Min. 20MΩ (at 500VDC megger)					
Vibration		1.5mm amplitude at frequency of 10 to 55Hz in each of X, Y, Z directions for 2 hours					
Shock		500m/s <sup>2</sup> (50G) in X, Y, Z directions for 3 times					
Protection		IP65(IEC standard)					
Material		Case: Aluminum					
Accessor	,	Bracket A: 4EA, Bracket B: 4EA, Bolt: 8EA					
Unit weight		Approx. 1.4kg(For 48 optical axes)					

### Input/Output circuit and connection diagram



### Timing diagram operation







Model	Cable length (L)	Connector color		
CID4-3T CID4-3R	3m			
CID4-5T CID4-5R	5m	Emitter(T) :Black		
CID4-7T CID4-7R	7m	Receiver(R) :Grav		
CID4-10T CID4-10R	10m	·Oldy		

### Installations


® For direction of installation Emitter and receiver should be installed in



For reflection from the surface of wall and flat When installing it as below, the light reflected from the surface of wall and flat is not shaded. Please check whether it operates normally or not with a sensing target before using. (Interval distance: Min. 0.5m)




It may cause interference when installing more than 2sets of the sensor. In order to avoid the interference of the sensor please install as following figures and use the interference protection function



Emitter1




elt should be installed out of the interference distanc




0.1 to 3m Min. 0.4m L×tan8° = L×0.14 min Min. 3m XIt may be a little different based on installation


### <Emitter> Model BW20-08(P) 3W40-04(P ÿ**₹** 22.6 BW20-12(P ð BW40-06(P

Dimensions





### Optical axis pitch/Number of optical axes/Sensing width



## Operation indicator

	Emitter		Receiver					
Item	Indicator		Indicator		Control			
	Green	Yellow	Green	Yellow	Red	output		
Power supply	≎	•	_	_	_			
MASTER operation	≎	•	_	_		_		
SLAVE operation	✡	✡	_	_	_	_		
Test input	✡	•	_	_	_	OFF		
Break of light emitting element	•	•	_	_	_	OFF		
Break of light emitting circuit	•	•	_	_	_	OFF		
Stable light ON	_	_	✡	•	•	ON		
Unstable light ON	_	_	≎	≎	•	ON	Displ	ay classification list
Unstable light OFF	_	_	•	≎	✡	OFF	≎	Lighting
Stable light OFF	_	_	•	•	≎	OFF		Light out
Break of light receiving circuit	_	_	•	▶	•	OFF	•	Flashing by 0.5sec.
Break of output element	_	_	▶	•	•	OFF	① ① or	Flashing simultaneously by
Synchronous line malfunction	_	_	•	•	•	OFF		0.5 sec.
Over current	_	_	•	•	1	OFF	⊚⊚	Cross-flashing by 0.5sec.
Ambient light received	_	_	•	•	•	OFF		Sequence-flashing
Emitter failure	_	_	₽	▶	€	OFF		by 0.5sec.
■ Troubleshootii	na							

### 

Malfunction	Cause	Troubleshooting			
Non-operation	Power supply  Cable incorrect connection or disconnection	Supply rated power. Check the wiring.			
	Rated connection failure	Use it within rated detecting distance.			
Non-operation in	Pollution by dirt of sensor cover	Remove dirt by soft brush or cloth.			
sometimes	Connector connection failure	Check the assembled part of the connector			
	Out of rated detecting distance	Use it within rated detecting distance.			
Control output is OFF even though there is not a target object.	There is an obstacle to cut off the light emitted between emitter and receiver	Remove the obstacle.			
	There is a strong electric wave or noise generator such as motor, electric generator, high voltage line etc.	Put away the strong electric wave or noise generator.			
LED displays for break of light emitting element	Break of light emitting element				
LED displays for break of light emitting circuit	eak of light emitting circuit				
LED displays for break of light receiving element	Break of light receiving element	Contact our company.			
LED displays for break of output element	Break of output element				
LED displays for synchronous line	Synchronous line incorrect connection or disconnection	Check the wiring.			
malfunction	Break of synchronous circuit of emitter or receiver	Contact our company.			
LED displays for over	Control output line is shorten	Check the wiring.			
current	Over load	Check the rated load capacity.			
LED displays for ambient light receiving	Ambient light received to receiver	Remove the ambient light.			
ED displays for emitter Emitter malfunction		Treat after checking the emitter display LED.			

### Caution for using

Please make the interval enough between 2 sets or exchange the positions of emitter and receiver in order to remove interference occurring by the emitter of another set when using emitter/receiver more than 2sets closely.

2. Please install this sensor at proper height(Min. approx. 0.5m) from flat part because malfunction may be caused due to certain amount of light received by light reflected when installing it close to flat part.

3. Avoid using this unit where there are fluorescent light with high frequency, high speed start or signal light affecting

Avoid using this unit where there are nuorescent again that regions of the control ability.
 Please use a single conduit or separated wiring as it may cause malfunction or mechanical trouble when installing the wiring of the sensor with high voltage lines.
 Avoid using this unit where there are these kinds of places with corrosive gas or dust as it may cause malfunction 6. Please make power and output line shorten as possible, or it may cause malfunction by surge etc.
 Please clean the sensor cover with dry cloth when it is stained by dirt etc., but do not use organic materials

8. When using switching power supply as the source of supplying power, Frame Ground (F.G.) terminal shall be grounded and a Switching power supply (SMPS)

(C.C.) retribilital state of grounded state of condenses for removing noise shall be installed between 0V and F.G. terminal.

9. Installation environment


9. Installation environment

2. Aktitude max. 2,000m Frame () () () () ③Pollution degree 2 4 Installation category

XIt may cause malfunction if above instructions are not followed.

### Major products

- Pressure sensors all achometer/Huse/t Rotary encoders
  Connector/Sockets Sensors or ordrollers
  Control switches/Lamps/Buzzers
  I/O Terminal Blocks & Cables
  Stepper motors/drivers/motion controllers
  Graphir/I onic panels Graphic/Logic panels
  Field network devices
  Laser marking system(Fiber, CO<sub>2</sub>, Nd:YAG)
  Laser welding/soldering system



# 454010 г. Челябинск, ул. Гагарина 5, оф. 507

тел. 8-800-775-09-57 (звонок бесплатный), тел.: (351)799-54-26, тел./факс (351)211-64-57 info@rusautomation.ru; www.rusaut русавтоматизация.рф

EP-KE-77-0004F