

Cylindrical Type Photoelectric Sensor

Features

[Common]

- Excellent noise immunity and minimal influence from ambient light
- Power/Output reverse polarity protection circuit, output short over current protection circuit
- Mutual interference prevention function (except through-beam type)
- · Sensitivity adjuster
- Light ON, Dark ON switchable by control wire

[BRQT, BRQM, BRQP Series (front sensing type)]


- Various materials: Plastic, Metal (Ni-plated Brass), Stainless steel 316L
- Long sensing distance: 30m (through-beam type)
- Body size BRQT, BRQM: Standard

BRQP: Standard, Short body

Protection structure - BRQT. IP67 (IEC standard), IP69K (DIN standard)
 BRQM, BRQP: IP67 (IEC standard)

[BRQPS Series (side sensing type)]

Protection structure: IP67 (IEC standard)





[BRQT, BRQM, BRQP Series (front sensing type)]



BRQT-A SUS316L Standard



BRQM-A Ni-plate Brass Standard



BRQP-A Plastic Standard



BRQP-B Plastic Short-body



Reflector (MS-2A)




Reflective tape (MST series)

[BRQPS Series (side sensing type)]







Reflective tape (MST series)

Ordering Information

%The model name with '-C' is connector type.
%Reflective tape (MST series) is sold separately.

(MS-2S)

RQ T		5	M]-	- 🔽	-	D	Т][[``[[Α -	- 🔽	7-[Р			,
Г'Т		T	1	_			Т	Т			Π	٦		Control		Front sensing type	Side sensing type
									- 1					output	No mark	NPN open collector of	output
															Р	PNP open collector of	output
													Conne	ction	No mark	Cable type	
															С	Connector type	
											App	oeara	ance		Α	Standard	Standard
															В	Short body ^{⋇1}	_
										Emi	tter/F	Recei	iver		1	Emitter	
									٠,						2	Receiver	
									Outp						-T	Transistor output	
							Р	owe	rsup	ply					D	DC power	
						Sor	cin	g ty	20						Т	Through-beam type	
						061	15111	y ty	Je						_P	Retroreflective type (
															D	Diffuse reflective type	е
				Sen	sing	dis	tand	ce u	nit						No mark	mm	
		٥	ensi	na c	liete	nco									M	m	
		L	01131	ng c	aiote	11100									Number	Sensing distance	
	F	orm o	of se	ensir	ng										No mark	Front sensing type	_
															S		Side sensing type
	Case r	mater	ial												Т	Stainless steel 316L	_
	34001														M	Brass, Ni-plate	_
Item															Р	Plastic	Plastic
IICIII															BRQ	Cylindrical type photo	oelectric sensor

Cylindrical Type Photoelectric Sensor (front sensing type)

Specifications

<u>e</u>	NPN collec	open tor output	BRQ□5M- TDT□-□	BRQ□20M- TDT□-□	BRQ□30M- TDT□-□	BRQ□3M- PDT□-□	BRQ□100- DDT□-□	BRQ□400- DDT□-□	BRQ□1M- DDT□-□	
Model	PNP (pen	BRQ□5M- TDT□-□-P	BRQ□20M- TDT□-□-P	BRQ□30M- TDT□-□-P	BRQ□3M- PDT□-□-P	BRQ□100- DDT□-□-P	BRQ□400- DDT□-□-P	BRQ□1M- DDT□-□-P	
Sen	Sensing type		Through-beam type			Retroreflective type (built-in polarizing filter)	(built-in Diffuse reflective type			
Sen	sing di	stance	5m	20m	30m	3m ^{×1}	100mm ^{*2}	400mm ^{*2}	1m ^{*3}	
Sen	sing ta	rget	Opaque materia	als of min. Ø7mr	n	Opaque materials of min. Ø75mm	Opaque, transl	Opaque, translucent materials		
Hys	eresis						Max. 20% at ra	ted sensing dista	ance	
-	ponse		Max. 1ms							
	er sup			0% (ripple P-P: ı	max.10%)					
Curr	ent co	nsumption	Emitter/Receive	er: max. 20mA		Max. 30mA				
	t sourc		Red LED (660n	,			Infrared LED (850nm)	Red LED (660	nm)	
		,	Sensitivity adjus							
Ope	ration	mode			by control wire (vhite)				
Con	trol out	put	NPN or PNP open collector output Load voltage: max. 30VDC=- · Load current: max. 100mA · Residual voltage: max. 2VDC=-							
Protection circuit		circuit	Power/Output reverse polarity protection circuit, output short over current protection circuit, interference prevention function (except through-beam type)							
India	cator		Operation indicator: yellow LED, stability indicator: green LED (emitter power indicator of through-beam type: red LED)							
Connection			Cable type, connector type							
Insu	lation r	esistance	Over 20MΩ (at 500VDC megger)							
Nois	e imm	unity	±240V the square wave noise (pulse width:1μs) by the noise simulator							
Diel	ectric s	trength	1,000VAC 50/60Hz for 1 minute							
Vibr	ation		1.5mm amplitude at frequency of 10 to 55Hz in each X, Y, Z direction for 2 hours							
Sho			500m/s² (approx. 50G) in X, Y, Z direction for 3 times							
승턴	Ambie	ent illu.	Sunlight: max. 11,000lx, Incandescent lamp: max. 3,000lx (receiver illumination)							
l S E	Ambie	ent illu. ent temp. ent humi.	-25 to 60°C, storage: -30 to 70°C							
			35 to 85%RH, storage: 35 to 85%RH							
Prot	ection	structure	BRQT Series: IP67 (IEC standard), IP69K (DIN standard) BRQM, BRQP Series: IP67 (IEC standard)							
Mate	erial		Case: BRQT Series - stainless steel 316L / BRQM Series - brass, Ni-plate / BRQP Series - polycarbonate Lens, Lens cover: polymethyl methacrylate acrylic							
Cab	le ^{*4}	Cable type			rough-beam type m, number of core		wire, 2m) lator out diameter: Ø1mm)			
1	.coon,	Individual	<u> </u>			Reflector (MS-2A) —				
ACCE	essory	Common	M18 fixing nut:	4, adjustment sc	rewdriver	M18 fixing nut: 2	M18 fixing nut: 2, adjustment screwdriver			
App	roval		(€c 91 0s							
Weight**	Cable	type	BRQP-A: appro	I-A: approx. 220 x. 160g (approx x. 150g (approx		BRQT-A/BRQM-A: approx. 150g (approx. 70g) BRQP-A: approx. 120g (approx. 60g) BRQP-B: approx. 120g (approx. 50g)				
Weig	Conne	ector type	BRQT-A/BRQM BRQP-A: appro	BRQT-A/BRQM-A: approx. 160g (approx. 50g) BRQP-A: approx. 110g (approx. 25g) BRQP-B: approx. 110g (approx. 15g) BRQP-B: approx. 100g (approx. 10g)						


^{※1:} The sensing distance is specified with using the MS-2A reflector. The distance between the sensor and the reflector should be set over 0.1m. When using reflective tapes, the reflectivity will vary by the size of the tape. Please refer to the '■ Reflectivity by Reflective Tape Model' table before using the tape.

- %2: Non-glossy white paper 100×100mm.
- X3: Non-glossy white paper 300×300mm.
- ※4: M12 connector cable is sold separately.
- X5: The weight includes packaging. The weight in parenthesis is for unit only.
- XThe temperature or humidity mentioned in Environment indicates a non freezing or condensation.


(unit: mm)

Dimensions


- Through-beam type
- BRQT□-TDTA(-P)
- BRQM□-TDTA(-P)




BRQT□-TDTA-C(-P)BRQM□-TDTA-C(-P)




BRQP□-TDTA(-P)




• BRQP□-TDTA-C(-P)




BRQP□-TDTB(-P)




• BRQP□-TDTB-C(-P)




- BRQT3M-PDTA(-P)/BRQM3M-PDTA(-P)
- BRQT□-DDTA(-P)/BRQM□-DDTA(-P)




- BRQT3M-PDTA-C(-P)/BRQM3M-PDTA-C(-P)
- BRQT□-DDTA-C(-P)/BRQM□-DDTA-C(-P)




- BRQP3M-PDTA(-P)
- BRQP□-DDTA(-P)




- BRQP3M-PDTA-C(-P)
- BRQP□-DDTA-C(-P)




- BRQP3M-PDTB(-P)
- BRQP□-DDTB(-P)



- BRQP3M-PDTB-C(-P)
- BRQP□-DDTB-C(-P)




• M18 fixing nut



⊚ Sold separately


Bracket(BK-BR-A)




Reflector

(unit: mm)

· MS-2A




• Fixing cap (BK-BR-B, only for BRQP B- B-)




• Connection cable


· CIDH4-



· CLDH4-



• Reflective tape




	(unit: mm)
Model	Α
MST-50-10	□50
MST-100-5	□100
MST-200-2	□200


■ Feature Data

Through-beam type


•BRQ□5M-TDT□-□(-P)




•BRQ□20M-TDT□-□(-P)




BRQ□30M-TDT□-□(-P)



○ Retroreflective type •BRQ□3M-PDT□-□-P




O Diffuse reflective type



■ Control Output Circuit Diagram

• Through-beam/Retroreflective/Diffuse reflective type



- ※If short-circuit the control output terminal or supply current over the rated specification, normal control signal is not output due to the output short over current protection circuit.

Connections for Connector Part




M12 Connector pin


	0-1-1-	Application					
Pin No.	Cable	Diffuse/	Through-beam type				
	COIOI	Retroreflective type	Emitter	Receiver			
1	Brown	30VDC	30VDC	30VDC			
2	White	CONTROL	N.C	CONTROL			
3	Blue	GND	GND	GND			
4	Black	OUTPUT	N C	OUTPUT			

Connector cable (sold separately)
 XPlease refer to the connector
 cable part.

Operation Timing Diagram

Through-beam type







**The waveforms of 'Operation indicator' and 'Transistor output' are for Light ON operation. They are opposite operation for Dark ON operation.


Connections

• Through-beam type











• Diffuse reflective type



<Connector type>

<Connector type>



Installation and Adjustment

Install the sensor to the desired place and check the connections. Supply the power to the sensor and adjust the optical axis and the sensitivity as following.


When using the reflective type photoelectric sensors closely over three units, it may result in malfunction due to mutual interference.

When using the through-beam type photoelectric sensors closely over two units, it may result in malfunction due to mutual interference.

When installing the product, tighten the screw with a tightening torque of 14.7N·m for BRQT/BRQM and 0.39N·m for BRQP.


Through-beam type

- Supply the power to the photoelectric sensor, after setting the emitter and the receiver facing each other.
- Set the receiver in center of position in the middle of the operation range of indicator adjusting the receiver or the emitter right and left, up and down.
- 3. After adjustment, check the stability of operation putting the object at the optical axis.
- ※If the sensing target is translucent body or smaller than
 Ø7mm, it can be missed by sensor cause light penetrate
 it.




Retroreflective type

- Supply the power to the photoelectric sensor, after setting the photoelectric sensor and the reflector (MS-2A) or reflective tape in face to face.
- Set the photoelectric sensor in the position which indicator turns on, as adjusting the reflector or the sensor right and left, up and down.
- 3. Fix both units tightly after checking that the unit detects the target.
- **XSensitivity adjustment**
 - : Refer to the diffuse reflective type's.




O Diffuse reflective type

 The sensitivity should be adjusted depending on a sensing target or mounting place.



- Set the target at a position to be detected by the beam, then turn the sensitivity adjuster until position (a) where the operation indicator turns ON from min. position of the Sensitivity adjuster.
- 3. Take the target out of the sensing area, then turn the Sensitivity adjuster until position (a) where the the operation indicator turns ON. If the indicator dose not turn ON, max. position is (b).
- 4. Set the sensitivity adjuster at the center of two switching position ⓐ, ⓑ.



Reflectivity by Reflective Tape Model

Model	Standard	Short body
MST-50-10 (50×50mm)	40%	40%
MST-100-5 (100×100mm)	50%	80%
MST-200-2 (200×200mm)	80%	85%

- XThis reflectivity is based on the reflector (MS-2A).
- ※Reflectivity may vary depending on usage environment and installation conditions.

The sensing distance and minimum sensing target size increase as the size of the tape increases.

- Please check the reflectivity before using reflective tapes.
- ※For using reflective tape, installation distance should be min 20mm

Cylindrical Type Photoelectric Sensor (side sensing type)

Specifications

del	NPN open collector output PNP open	BRQPS10M- TDTA(-C)	BRQPS20M- TDTA(-C)	BRQPS3M- PDTA(-C)	BRQPS100- DDTA(-C)	BRQPS400- DDTA(-C)	BRQPS700- DDTA(-C)			
Mo	PNP open collector output	BRQPS10M- TDTA(-C)-P	BRQPS20M- TDTA(-C)-P	BRQPS3M- PDTA(-C)-P	BRQPS100- DDTA(-C)-P	BRQPS400- DDTA(-C)-P	BRQPS700- DDTA(-C)-P			
Ser	sing type	Through-beam type		Retroreflective type (built-in polarizing filter)		Diffuse reflective type				
Ser	sing distance	10m	20m	3m ^{*1}	100mm ^{*2}	400mm ^{*2}	700mm ^{*3}			
Ser	sing target	Opaque materials of	of min. Ø7mm	Opaque materials of min. Ø75mm	Opaque, translucent materials					
Hys	teresis	_			Max. 20% of max	imum sensing dist	ance			
Res	ponse time	Max. 1ms								
Pov	ver supply	10-30VDC== ±10%	(ripple P-P: max. 1	0%)						
Cur	rent consumption	Emitter/Receiver: n	nax. 20mA	Max. 30mA						
Ligh	nt source	Red LED (660nm)								
		Sensitivity adjuster								
Оре	eration mode	Selectable Light Of	N or Dark ON by co	ntrol wire (white)						
Cor	itrol output	NPN or PNP open collector output Load voltage: max. 30VDC Load current: max. 100mA • Residual voltage: max. 2VDC								
Protection circuit Power/Output reverse polarity protection circuit, output short over current protection circuit, interference prevention function (except through-beam type)										
Indi	cator	Operation indicator	yellow LED, stabilit	y indicator: green LE	D (emitter power i	ndicator of through	-beam type: red LED)			
Cor	nection	Cable type, connec	tor type							
Inst	llation resistance	Over 20MΩ (at 500	VDC megger)							
Noi	se immunity	±240V the squre w	the squre wave noise (pulse width: 1µs) by the noise simulator							
Die	ectric strength	1,000VAC 50/60Hz	for 1 minute							
Vib	ation	1.5mm amplitude a	t frequency of 10 to	55Hz in each X, Y,	Z direction for 2 ho	ours				
Sho		500m/s2 (approx. 5	0G) in X, Y, Z direct	ions for 3 times						
Environ-	Ambient illu.	Sunlight: max.11,00	00lx, incandescent l	amp: 3,000lx (receiv	er illumination)					
] ≥ S	Ambient temp.	-25 to 60°C, storage	e: -30 to 70°C							
п,	Ambient humi.	35 to 85%RH, stora	age: 35 to 85%RH							
Pro	tection structure	IP67 (IEC standard)							
Mat	erial	Case: polycarbona	te, lens, lens cover:	polymethyl methaci	ylate acrylic					
Cat	ole ^{**4}			beam type: Ø4mm, ber of cores: 20, ins		er: Ø1mm)				
Λ.00	Individual	_		Reflector (MS-2S)	_					
ACC	Common	M18 fixing nut: 4, ad	justment screwdriver	M18 fixing nut: 2, ad	justment screwdrive	er				
App	roval	(€ c % us								
Wei	ght Cable type	Approx. 170g (appi	rox. 120g)	Approx. 130g (appr	rox. 70g)					
₩5	Connector type	Approx. 120g (appr	rox. 35g)	Approx. 120g (appi	rox. 25g)					
						10 0 1	uld be set ever 0.1m			

^{X1: The sensing distance is specified with the MS-2S reflector. The distance between the sensor and the reflector should be set over 0.1m. When using reflective tapes, the reflectivity will vary by the size of the tape. Please refer to the '■ Reflectivity by Reflective Tape Model' table before using the tape.}

^{※2:} Non-glossy white paper 100×100mm.

X3: Non-glossy white paper 200×200mm.


X4: M12 connector cable is sold separately.

X5: The weight includes packaging. The weight in parenthesis is for unit only.

XThe temperature and humidity mentioned in Environment indicates a non freezing or condensation.


■ Dimensions (unit: mm)

- O Through-beam type
- BRQPS□-TDTA(-P)
- ·Emitter




BRQPS□-TDTA-C(-P)


· Emitter



·Receiver




·Receiver




- Retroreflective/Diffuse reflective type
- BRQPS□-DDTA(-P)
- BRQPS3M-PDTA(-P)

- BRQPS□-DDTA-C(-P)
- BRQPS3M-PDTA-C(-P)




• M18 fixing nut



Reflector


(unit: mm)

· MS-2S




⊚ Sold separately

• Bracket(BK-BR-A)




• Reflective tape




	(unit: mm)
Model	Α
MST-50-10	□50
MST-100-5	□100
MST-200-2	□200

• Connection cable









%Specification of connector cable: Ø6mm, 4-wire, 2m/3m/5m/7m
(AWG22, core diameter: 0.08mm, number of cores: 60, insulator out diameter: Ø1.65mm)


■ Feature Data

O Diffuse reflective type

◎ Diffuse reflective type• BRQPS100-DDTA-□(-P)


• BRQPS400-DDTA-□(-P)

• BRQPS700-DDTA-□(-P)




Retroreflective type

BRQPS3M-PDTA-□(-P)




○ Through-beam type

• BRQPS10M-TDTA-□(-P)




BRQPS20M-TDTA-□(-P)



■ Control Output Circuit Diagram

Through-beam/Retroreflective/Diffuse reflective type



**Before using this unit, select Light ON/Dark ON with control wire. (Light ON: connect control wire to 0V/Dark ON: connect control wire to +V) If short-circuit the control output terminal or supply current over the rated specifi cation, normal control signal is not output due to the output short over current protection circuit

Connections for Connector Part




M12 Connector pin

	0-1-1-	Application				
Pin No.	Cable color	Diffuse/	Through-beam type			
	COIOI	Retroreflective type	Emitter	Receiver		
1	Brown	30VDC	30VDC	30VDC		
2	White	CONTROL	N.C	CONTROL		
3	Blue	GND	GND	GND		
4	Black	OUTPUT	N.C	OUTPUT		


 Connector cable (sold separately) XPlease refer to the connector cable part.

Operation Timing Diagram

Through-beam type




O Retroreflective/Diffuse reflective type




XThe waveforms of 'Operation indicator' and 'Transistor output' are for Light ON operation. The waveforms are reversed in Dark On operation.


Connections

• Through-beam type





• Retroreflective type





• Diffuse reflective type





■ Installation and Adjustment

Install the sensor to the desired place and check the connections.

Supply the power to the sensor and adjust the optical axis and the sensitivity as following.


When using the reflective type photoelectric sensors closely over three units, it may result in malfunction due to mutual interference.

When using the through-beam type photoelectric sensors closely over two units, it may result in malfunction due to mutual interference.

When installing the product, tighten the fixing nuts with a tightening torque of $0.39N \cdot m$.


Through-beam type

- Supply the power to the photoelectric sensor, after setting the emitter and the receiver facing each other.
- Set the receiver in center of position in the middle of the operation range of indicator adjusting the receiver or the emitter right and left, up and down.
- 3. After adjustment, check the stability of operation putting the object at the optical axis.
- ※If the sensing target is translucent body or smaller than Ø7mm, it can be missed by sensor cause light penetrate it.




Retroreflective type


- Supply the power to the photoelectric sensor, after setting the photoelectric sensor and the reflector (MS-2S) or reflective tape in face to face.
- Set the photoelectric sensor in the position which indicator turns on, as adjusting the reflector or the sensor right and left, up and down.
- 3. Fix both units tightly after checking that the unit detects the target.
- **X**Sensitivity adjustment
 - : Refer to the diffuse reflective type's.



O Diffuse reflective type

- 1. The sensitivity should be adjusted depending on a sensing target or mounting place.
- Set the target at a position to be detected by the beam, then turn the sensitivity adjuster until position (a) where the operation indicator turns ON from min. position of the sensitivity adjuster.
- Take the target out of the sensing area, then turn the sensitivity adjuster until position
 where the the operation indicator turns ON.
 - If the indicator dose not turn ON, max. position is **(b)**.
- 4. Set the sensitivity adjuster at the center of two switching position ⓐ, ⓑ.
- **Be aware of the fact that sensing distance can be different by size, surface and gloss of the target.





Reflectivity by Reflective Tape Model

MST-50-10 (50×50mm)	25%
MST-100-5 (100×100mm)	30%
MST-200-2 (200×200mm)	35%

- **This reflectivity is based on the reflector (MS-2S).
- ※Reflectivity may vary depending on usage environment and installation conditions.

The sensing distance and minimum sensing target size increase as the size of the tape increases.

Please check the reflectivity before using reflective tapes.

%For using reflective tape, installation distance should be min 20mm