# **Cautions during Use**

- · Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
- WARNING Normally Open (NO) Contacts cannot be used for emergency stop control circuits.
- Emergency stop pushbuttons are UL NISD Listed when mounted in a sealed, nonventilated enclosure only.
- When installing the product, keep the minimum installation space between units.
- While wiring or after wiring the contact block, do not pull the cable.
- Do not hit or flip the button, and use hand not any tool to push the button
- To unlock the switch, turn the button approximately 45° clockwise, and do not turn the button with excessive force.
- This unit may be used in the following environments.
- Indoors (in the environment condition rated in 'Specifications')
- Altitude max. 2,000m
- Pollution degree 3
- Installation category III

# **Ordering Information**

This is only for reference. For selecting the specific model, follow the Autonics web site.

0			· ·					
SF2ER	-	Ε	0	R	0	-	€	
Button				(	3 Mark			
1: D30 (short h	ead, no	n-illum	inated)	Ν	lo-mark	: No-m	iark	

A: EMO S: EMS

1: D30 (short head, non-illuminated) 2: D40 (short head, non-illuminated)

#### Ontact block

B: B contact: 1 AB: A contact: 1, B contact: 1 2B: B contact: 2 A2B: A contact: 1. B contact: 2 3B: B contact: 3

# SF2ER Series

#### For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.

The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice.

# Main Features

- · Easy mounting and removing of Contact Units using a lever
- Adoptable maximum three contact units in series to improve wiring efficiency
- Available to install using either round or forked crimp terminals
- Oil resistant to IP65 protection structure
- · Circuit interruption function with a direct opening mechanism for the occurrence of error such as contact weld
- · Supplying a various kind of accessories for improving usability : Protection guard ring for preventing malfunction from crash by a user
  - (responding to SEMI-S2)
- : Name plate Ø60/Ø90
- : Radial support

Specifications

Model	SF2ER-
Mouet	
Rated voltage/current	IEC: AC-15 (220 VAC~, 3 A), DC-13 (220 VDC=, 0.2 A) UL: A300, Q300
Contact operating power	3.0 to 8.0 N/ 1 contact
Operation distance	5.0 mm (0/-0.5)
Rotation angle	CW (clock wise) 52 °
Allowable operation frequency <sup>01)</sup>	Mechanical: 20 times/minute Electrical: 20 times/minute
Life cycle	Mechanical: Min. 250,000 times Electrical: Min. 100,000 times
Applicable wire	AWG 18 (0.823 mm <sup>2</sup> )
Insulation resistance	$\geq$ 100 M $\Omega$ (500 VDC== megger)
Dielectric strength	2,500 VAC~ 50/60 Hz for 1 minute
Vibration	1.5 mm double amplitude at frequency of 10 to 55 Hz (for 1 min) in each X, Y, Z direction for 2 hours
Vibration (malfunction)	1.5 mm double amplitude at frequency of 10 to 55 Hz (for 1 min) in each X, Y, Z direction for 10 minutes
Shock	1,000 m/s <sup>2</sup> ( $\approx$ 100 g) in each X, Y, Z direction for 3 times
Shock (malfunction)	250 m/s <sup>2</sup> ( $\approx$ 25 g) in each X, Y, Z direction for 3 times
Ambient temperature	-20 to 65°C <sup>02)</sup> , storage : -40 to 70 °C (at no freezing or condensation)
Ambient humidity	35 to 85 %RH , storage : 35 to 85 %RH (at no freezing or condensation)
Protection structure	IP65 <sup>03)</sup> (oil resistant, IEC standards)
Material	Button: PC, BODY: PA6, lever in fixing unit: PA6
Approval	( E C But LETER RAYNORD S
Weight <sup>04)</sup>	≈ 66g

01) Setting and resetting once is counted as one operation.

 2) UL approved ambient temperature: 55 °C
03) It is only for part from front of the panel. Protection structure is guaranteed only when the switch is installed on flat and smooth surface with mounting holes Ø22mm

04) It is switch with three contact blocks.



# **Rus**Automation

# Ø22/25 mm Round Mount Emergency Stop Switches



### Contact capacity

• IEC (EN60947-5-1)

Rated current		10 A					
Rated	voltage	24 V	110 V	220 V	380 V		
AC	Resistive load (AC-12)	10 A	10 A	6 A	3 A		
AC	Inductive load (AC-15)	10 A	5 A	3 A	2 A		
DC	Resistive load (DC-12)	10 A	2 A	0.6 A	0.2 A		
DC	Inductive load (DC-13)	1.5 A	0.5 A	0.2 A	0.1 A		

• UL / CSA (UL508, CSA C22.2 No. 14)

A300

	Through	Current (A)		Volt ampere (VA)	
voltage	current	Making	Breaking	Making	Breaking
AC120 V	10 A	60	6	7,200	720
AC240 V	10 A	30	3	7,200	120
Q300 Rated	Through	Current (A)		Volt ampe	re (VA)
	Through current	Current (A) Making	Breaking	Volt amper Making	re (VA) Breaking
				- ·	

## Dimensions

• Unit: mm, For the detailed drawings, follow the Autonics web site.

## ■ D30 (short head, non-illuminated)





#### D40 (short head, non-illuminated)



# Panel cut-out



# **Parts Descriptions**



# Installation and Remove

#### Installing

- 1. Insert the button unit from the front side of panel in the ① direction.
- 2. Insert the fixing nut from the rare side of panel in the ② direction.
- 3. Turn the fixing nut in the ③ direction to tighten.
- Before tightening the fixing nut, be sure that there is rubber washer between the switch and panel.
- 4. Put the operation unit to the button unit in the ④ direction.



## Removing

- 1. Turn the lever in the ① direction using the screwdriver.
- 2. Pull the operation unit in the ② direction to disassemble it.
- 3. Release the fixing nut in the ① direction to disassemble it.



### **Contact block**

#### Assembling contact block

Insert the contact block in the arrow direction.



# Disassembling contact block

Lift up the lever in the arrow direction with the screwdriver and to disassemble the contact block.



## Wiring

39.2

А

≥ 33 mm

> 55 mm

D30

D40

- When wiring contact block, use phillips or slotted M3.5 screws with square washer.
- Applicable wire: AWG 18 (0.823 mm<sup>2</sup>)
- Tightening torque: 0.6 to 0.8 N · m
- Please use UL certified terminals.



454010 Россия, Челябинск, Гагарина 5, тел. 8-800-775-09-57 (звонок бесплатный), +7(351)799-54-26, тел./факс +7(351)211-64-57, info@rusautomation.ru, www.rusautomation.ru, русавтоматизация.рф